




INKQUBO YOVIWO: ISISTIM YOKHUSELEKO I-SMARTLOCK SECURITY SYSTEM

A. UKULUNGISELELA I-GRIDLOCK ACCESS MANAGEMENT SOLUTION (GLAM SMART KEY)

Kufuneka ulungiselele i-GLAM Smart Key ubuncinane **kwiyure enesiqathanga** phambi kweseshoni nganye.

1. Cofa uvule i-GLAM Smart Key ngokucinezela ubambe iqhosha lokuvula uvale  kude kubonakale ilayithi kwiskrini sokubonisa yaye ilayithi eluhlaza okwengca ihlala izinzile.
2. I-blue bar (Data bar) iya kunqamleza iskrini sokubonisa yaye mayifundeke ngolu hlobo "DATA TRANSFER BUSY". Lindela i-GLAM Smart Key ibe kwimo yokuba "READY" phambi kokwenza nayiphi imisebenzi.
3. **Kucelwa unike imizuzwana embalwa ukuze i-GPS ne-GSM zibe nokuqhagamshelana.** I-ayikhoni yesathalayithi iya kujika ibe tyheli.

B. UKUKHUPHELA (DOWNLOADING) IISHEDYULI

NgoLwesibini/ngoLwesithathu ngamnye weveki ngeveki nganye ngethuba loviwo, kuya kuthunyelwa i-imeyili neSMS kwinqununu/kumphathi weziko kwanomyalelo wokukhuphela (download) isikolo esithile okanye iishedyuli/iiseshoni zeziko lokubhalela uviwo.

1. Qinisekisa ukuba i-GLAM Smart Key ikwimo u-"READY".
2. **Cofa amaqhosha okutshixa nokuvula ngaxeshanye ukukhuphela iishedyuli/iiseshoni ezikhoyo. Lo gama i-"DATA TRANSFER BUSY" ibonakala, lindela umbala OLUHLAZA OKWENGCA, emva koko kulandele ii-BLUE transfer bars, ukunqamleza iskrini.** Emva kokuba inkqubo yokukhuphela seyigqitywe ngempumelelo, inani leeshedyuli/leeseshoni ezikhoyo liya kuvela kwiqhaga elityheli kumphezulu weskrini sokubonisa. Ezi seshoni zinokungqinisiswa kwi-GLAM Smart Key ngokucofa iqhosha lokuvula nokuvula kube kanye. Unokuskrola iiseshoni zonke ngokucinezela iqhosha lokuvula nokuvula lonke ixesha.
3. I-GLAM Smart Key ngoku ikulungele **ukusetyenziswa.**

C. INKQUBO YOKUVULA

Mayenziwe **kwiyure phambi** kweseshoni yoviwo nganye.

1. FAKA **NGOKUPHELELEYO** i-GLAM Smart Key KWITYWINA ELIBOMVU. Qinisekisa ukuba uqhagamshelwano phakathi kwe-GLAM Smart Key netywina elibomvu luhlala luzinzile.
2. Cinezela iqhosha u-**UNLOCK UNGAWUSUSI** umnwe ide inkqubo ye-"Unlocking and transfer" igqitywe (lindela ibha eluhlaza okwengca emva koko kubonakale ibha eblowu enqamleza kwiskrini **ngokupheleleyo**).
3. **SUSA I-GLAM SMART KEY WANDULE UKUVULA ITYWINA** (umxokelelwano) nje ukuba ibe yimpumelelo inkqubo i-"AUTHORISED UNLOCKING" (**itywina alisayi kuvula lo gama i-GLAM Smart Key isekwitywina elibomvu**).

D. INKQUBO YOKUTSHIXA

Mayenziwe **ingadlulanga iyure emva** kokugqitywa kweseshoni yoviwo nganye.

1. Qinisekisa ukuba itywina livaliwe yaye lihleli kakuhle phezu kwekhonkco (hasp) lesingxobo esimnyama.
2. FAKA i-GLAM Smart Key kwitywina elibomvu (qinisekisa ukuba uqhagamshelwano phakathi kwe-GLAM Smart Key netywina elibomvu luzinzile).
3. Cinezela iqhosha u-**LOCK** yaye **UNGAWUSUSI** umnwe ide inkqubo ye-"Locking and transfer" ide ibe kanti igqitywe (lindela ibha eluhlaza okwengca emva koko kunqamleze ibha eblowu kwiskrini **ngokupheleleyo**).
4. Yakuba nje igqitywe inkqubo yokutshixa, lindela ukuba i-"DATA TRANSFER" yenzeke igqitywe.
5. **QAPHELA:** Qinisekisa ukuba i-GLAM Smart Key ihlala itshajiwe yaye nebhetri isebenza ngokupheleleyo ngalo lonke ithuba loviwo.

UKUKOPELA (DOWNLOAD) IISHEDYULI/IISESHONI KWI-GLAM SMART KEY



Cofa amaqhosha okuvula nokuvula (*lock and unlock buttons*) ngaxeshanye.

IINKCUKACHA ZOQHAGAMSHELWANO ZABO KUDLULISELWE KUBO AMAGUNYA ESIKOLWENI

IGAMA LESIKOLO: _____

INOMBOLO YEFOWUNI YESIKOLO: _____

IGAMA LENQUNUNU	INOMBOLO YESELULA.	IDILESI YE-IMEYILI

IGAMA LESEKELA NQUNUNU	INOMBOLO YESELULA.	IDILESI YE-IMEYILI

IGAMA LELUNGU LE-SMT	INOMBOLO YESELULA.	IDILESI YE-IMEYILI

ISIGNITSHA YENQUNUNU

UMHLA

ISITAMPU SESIKOLO

UKUNGQINISISA (VERIFY) IISESHONI EZIKOTSHELWEYO (DOWNLOADED)



Oku kungqinisisa kumele ukwenziwa emva kokuba kukotshelwe umthwalo ngamnye kwi-GLAM Smart Key.